




ASSEMBLY INSTRUCTION

5429-24ST ADJUSTABLE STOOL

A



Leg Frame
1PC

B



Leg
2PCS

C



Bottom Ring
1PC

D



Center Ring
1PC

E



Seat
1PC

F




Metal Plate and Pole
1PC


HARDARE LIST

G		Bolt with Lock Washer and Flat Washer	1/4"X12mm	5pcs
H		Bolt with Lock Washer and Flat Washer	1/4"X15mm	12pcs
I		Flat Washer	ø28mm	1pc
J		L-Allen Key	4mm	1pc



STEP 1



STEP 2



STEP 3



Step 1. Attach Leg (B) to Leg Frame (A) ,insert Bolt (G) then tighten with Allen Key (J).


Step 2. Attach Bottom Ring (C) to legs,insert Bolt (H) then tighten with Alen Key(J).

Step 3. Attach Center Ring (D) to Legs,insert Bolt (H) then tighten with Allen Key(J).


ASSEMBLY INSTRUCTION

5429-24ST ADJUSTABLE STOOL


STEP 4




STEP 5



STEP 6



COMPLETED.



Step 4. Upside down Seat (E) and attach Metal Plate and Pole (F) to it,insert Bolt (H) then tighten with Allen Key(J).

Step 5. Rotate Metal Plate and Pole (F) to Leg Frame (A) to the proper position .

Step 6. Attach Flat Washer (I) to Metal Plate and Pole (F) ,insert Bolt (G) then tighten with Allen Key (J).

▲ For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.