







Assembly Instruction

ITEM NO. 9928BLK/DBR-3

DOUBLE RECLINING SOFA WITH DROP DOWN CUP-HOLDERS

NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


PARTS LIST

NO.	DRAWING	QTY	DESCRIPTION
A		1	LSF BACK REST
B		1	MIDDLE BACK REST
C		1	RSF BACK REST
D		1	LSF EAR
E		1	RSF EAR
F		1	SEAT


Please follow the drawings below to assemble the item.

Step 1. Align the female brackets at the back rest onto the male brackets at the seat, insert and push to the end, make sure the brackets are secured in position.


Step 2. Insert the LSF ear and RSF ear to the back rest and make sure it is secured in position.



Step 3. Completed.



Step 4. Pull the middle back rest to the front to use cup holder.



CARE INSTRUCTION FOR PU FURNITURE

- Avoid exposing furniture directly to sunlight or heating and air conditioning Outlets. Exposure to sunlight or heating and air conditioning outlets will fade/ Damage PU.
- Wipe gently with a damp soft cloth to remove dust, dirt and any grime buildup.
- Wipe PU with professional cleanser



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration