



Item#1704-60: ROUND DINING TABLE



Note: Hardware pack is in 1704-60




This page lists all the contents included in the box. Please take time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.


Made in Vietnam



Attach the upper cross bar (D), lower cross bar (E) to the center finial (G)




Attach the leg (C) with 4pcs bolt (H), 4pcs flat washer (J), 4 pcs spring washer (K), then tighten using allen key (L).




3


Attach the base (F) to the legs (C) with 8pcs bolt (I), 8pcs flat washer (J), 8pcs spring washer (K), then tighten using allen key (L).



4


Attach the mounting plate (B) to the legs (C) with 4pcs hex nut (M), 4pcs flat washer (N), 4pcs spring washer (O), then tighten using wrench (P).







Attach mounting plate (B) to table top (A) with 8pcs bolt (H), 8pcs flat washer (J), 8 pcs spring washer (K), then tighten using allen key (L).



Cleaning & Care

Treat surface with care. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.