



# ASSEMBLING INSTRUCTIONS

ITEM NO: 1051BE-1/ 1051BU-1/ 1051DG-1


Accent Chair

Legs and hardware are stored in the bottom of the seat, please take them out for assembly.

**!** Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

PART	DRAWING	DESCRIPTION	QTY	PART	DRAWING	DESCRIPTION	QTY
A		Frame	1 PC	1		Bolt Ø5/16"×1"	8 PCS
B		Seat Frame	1 PC	2		Bolt Ø5/16"×1-3/4"	6 PCS
C		Seat Cushion	1 PC	3		Spring Washer Ø5/16"	14 PCS
D		Back Cushion	1 PC	4		Flat Washer Ø5/16"×3/4"	14 PCS
E		Metal Leg 3-5/32"x3-5/32"x5-3/4"	4 PCS	5		Allen Key M4	1 PC

## STEP 1:







# ASSEMBLING INSTRUCTIONS

ITEM NO: 1051BE-1/ 1051BU-1/ 1051DG-1

Accent Chair

STEP 2:






# ASSEMBLING INSTRUCTIONS


ITEM NO: 1051BE-1/ 1051BU-1/ 1051DG-1

Accent Chair

## STEP 3:



COMPLETE



### Care Instruction for Chenille Furniture:

In order to maintain the original appearance of your Chenille furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage Chenille.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary

**⚠** For item use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.