



# Assembly Instruction






ITEM NO. 1109BU/GY-1 ACCENT CHAIR



Legs and hardware are packed in a small box and placed on the seat. Please take out for assembly.


NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.

## PART LIST


NO.	DRAWING	QTY	DESCRIPTION
A		1pc	CHAIR
B		1pc	SEAT CUSHION
C		2pcs	WOODEN FRONT LEG LSF/RSF
D		2pcs	WOODEN REAR LEG LSF/RSF
E		4pcs	PLASTIC GASKET

**NOTE:**Please follow the drawings below to assemble the item.


**Step 1:**Legs and hardware are packed in a small box and placed on the seat. Please take out for assembly.



**Step2:**



**Step3:**



## CARE INSTRUCTION FOR 100% POLYESTER FURNITURE:

In order to maintain the original appearance of your 100% polyester furniture, please follow below simple care procedure:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage 100% polyester.
- Wipe gently with a damp soft cloth to remove dust, dirt and any grime buildup.

⚠ For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and support to avoid/prevent from damages/scratches and discoloration.