

ASSEMBLY INSTRUCTIONS


INSTRUCTIONS D'ASSEMBLAGE

ITEM NO. : 1118GY-1
Accent Chair/ Fauteuil Accent


▲ It is recommended to install protective pads under all legs and supports to avoid damage or scratches when placing furniture on a wood floor or other hard surface, and to limit indentation and prevent discoloration if placing on carpet.

▲ Il est recommandé de placer des coussins protecteurs sous tous les pieds et toutes les bases des meubles pour éviter d'endommager ou d'égratigner les planchers en bois ou autres surfaces dures, et pour limiter l'empreinte et empêcher la décoloration quand les meubles reposent sur la moquette.

HARDWARE LIST/ LISTE DE QUINCAILLERIE PARTS LIST/ LISTE DE PIÈCES

NO.	DESCRIPTION	SKETCH	SIZE	QTY
A	BOLT		Ø1/4" x 32mmL	16 PCS
B	SPRING WASHER		Ø1/4"	16 PCS
C	FLAT WASHER		Ø1/4" x 19mm	16 PCS
D	ALLEN KEY		4mm	1 PC

NO.	DESCRIPTION	DRAWING	QTY
1	SEAT FRAME		1 PC
2	WOODEN LEG		4 PCS



Assembly Completed


ASSEMBLY INSTRUCTIONS

INSTRUCTIONS D'ASSEMBLAGE

ITEM NO. : 1118GY-1
Accent Chair/ Fauteuil Accent


STEP 1/ ÉTAPE 1:

Please remove the Wooden Leg Box from Seat Frame (1) before assembly.




STEP 2/ ÉTAPE 2:

Attach Wooden Leg (2) to Seat Frame (1) by using Bolt (A), Spring Washer (B), Flat Washer (C) and Allen Key (D).



Assembly Completed



CARE INSTRUCTION FOR POLYESTER FURNITURE

In order to maintain the original appearance of your polyester furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage polyester. Do not place your upholstered furniture too close to windows, radiators, vents and be sure to use window treatments to block the sun's rays.

- Use soft brush to remove dust.