







# Assembly Instruction

ITEM NO.: 8347BRW/CRC-2  
Double Reclining Love Seat With  
Center Console





Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

## COMPONENT LIST



| No | Drawing   | Description       | Qty  |
|----|---|-------------------|------|
| A  |    | SEAT              | 1 PC |
| B  |   | LSF BACK REST     | 1 PC |
| C  |  | CONSOLE BACK REST | 1 PC |
| D  |  | RSF BACK REST     | 1 PC |
| E  |  | LSF EAR           | 1 PC |
| F  |  | RSF EAR           | 1 PC |

## Step #1


Console back rest(C) and Ears(E/F) are stored under metal frame




## Step #2



## Step #3





## Care Instruction for Polished Microfiber Furniture:

In order to maintain the original appearance of your Polished Microfiber Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Polished Microfiber.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.