






Assembly Instruction


CHAIR
ITEM# : 9318CBN-1 CHAIR

PART LIST				HARDWARE LIST				
A	CHAIR FRAME		1 PC	1	ALLEN KEY		5 x 75 mm	1 PC
B	SEAT CUSHION		1 PC	2	BOLT		5/16 x 4"	8 PCS
C	BACK CUSHION		1 PC					
D	WOODEN LEG		4 PCS					

STEP 1



STEP 2



Care instruction for textured plush microfiber Furniture:

In order to maintain the original appearance of your textured plush microfiber furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage textured plush microfiber.
- Vacuum or wipe with a soft cloth to remove dust.

For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.

