











Legs & hardware are stored in the bottom of seat, please take out for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


## Component list

| No | Drawing                                                                             | Qty | Description         |
|----|-------------------------------------------------------------------------------------|-----|---------------------|
| A  |    | 4   | WOODEN LEG H:4 INCH |
| B  |   | 2   | BACK CUSHION        |
| C  |  | 1   | LSF ARM             |
| D  |  | 1   | RSF ARM             |
| E  |  | 1   | BACK REST           |
| F  |  | 1   | SEAT                |


### Step #1




## Step #2




## Step #3




## Step #4



## Step #5



## Step #6



## Care Instruction for Textured Fabric Furniture:

In order to maintain the original appearance of your textured fabric Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage textured Fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.