








Assembly Instruction

LOVESEAT

ITEM NO. : 9814BU-2/9814GY-2


NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

COMPONENT LIST

NO.	DRAWING	QTY	DESCRIPTION
A		1	SEAT FRAME
B		1	BACK REST
C		2	CUSHION
D		4	LEG
E		8	BOLT(5/16"×35MM)
F		8	FLAT WASHER (5/16"×22MM)
G		1	ALLEN KEY($\frac{5}{16}$ ")


STEP1:

Align and insert the back rest, push to the end to secure it.




STEP2


Align the legs to the pre-drilled holes at the bottom of the units, insert bolts and washers then tighten with screw driver Allen Key




STEP3 :
Put the Cushion (C) to the Seat Frame(A).



STEP4
Assembly completed.





Care instruction for Polyester furniture.

In order to maintain the original appearance of your Polyester furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets.

Sunlight and/or exposure to heating and air conditioning outlets will fade/damage fabrics.

Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.

- Vacuum or wipe with a cloth regularly to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.